






Closure screw

Closure screw	NP	RP
 051.1310		 051.2310


Prosthetic components

Healing cap	NP	RP
	Conical	Conical
	3.0mm	3.0mm
	5.0mm	5.0mm
	Curve	Curve
	3.0mm	3.0mm
	5.0mm	5.0mm


Angled abutment	NP	RP
	0°	0°
	1.5mm	1.5mm
	15°	15°
	1.5mm	1.5mm



Narrow abutment	NP	RP
	7.0mm	7.0mm
	9.0mm	9.0mm




Temporary abutment(bridge)	NP	RP
	1.5mm	1.5mm
	053.1241	053.2241

Locator	NP	RP
		
	052.1631	052.2631

H=1.0mm	052.1631	052.2631
H=2.0mm	052.1632	052.2632
H=3.0mm	052.1633	052.2633
H=4.0mm	052.1634	052.2634
H=5.0mm	052.1635	052.2635
H=6.0mm	052.1636	052.2636



Temporary cylinder R	
	053.1561



Abutment	NP	RP
	0.5mm	0.5mm
	1.0mm	1.0mm
	1.5mm	1.5mm
	0.5mm	0.5mm
	1.0mm	1.0mm
	1.5mm	1.5mm






Multi-unit abutment	NP	RP
	0°	0°
	1.5mm	1.5mm
	17°	17°
	1.5mm	1.5mm
	30°	30°
	1.5mm	1.5mm

Abutment screw	NP	RP
	051.1416	051.2411
	051.1414	051.2413
	051.1412	

Impression components

Impression tray (closed tray)	NP	RP
	3.6mm	3.6mm
	5.0mm	5.0mm
	6.0mm	6.0mm
	3.6mm	3.6mm
	5.0mm	5.0mm
	6.0mm	6.0mm

Impression tray (open tray)	NP	RP
	3.6mm	3.6mm
	5.0mm	5.0mm
	6.0mm	6.0mm
	3.6mm	3.6mm
	5.0mm	5.0mm
	6.0mm	6.0mm

Impression tray (open tray)	For bridge	For multi-unit	Analog	For multi-unit
				
NP 058.1107	RP 058.2113	058.1109	NP 058.1201	RP 058.2201
				038.1384